




BLU-RAY

Changing Blu-Ray Region Settings

The Sony Blu-Ray players need to have their region changed to match the region indicated on the Blu-Ray case.



Note: Changing Regions is unnecessary for DVDs.

- 1** Turn off the Blu-Ray player.
- 2** On the remote, press the correct color for your Blu-Ray's region.
 -  Yellow for Region A
 -  Blue for Region B
 -  Red for Region C
- 3** The player should then turn on and you can play your disc as normal.

